

Description	P/N	TYPE	160	161	200	201	250	251	320	321
Space cover	46000/48000	BS+TS								
Gas inlet casing	50	A1/A20radial 2 holes	√	√	√	√	√	√	√	√
Gas inlet casing	50	A9/A21axial 2 holes				√		√		
Gas inlet casing	50	A11/A15radial 1 hole						√		
Gas inlet casing	50	AA31axial 3 holes								
Gas inlet casing	51000	AA12/AA21								
Gas inlet casing	51000	AA11								
Gas inlet casing	51000	AA11/21/31								
Gas inlet casing	51000	AA11 one hole								
Gas inlet casing	51000	AA21 two holes								
Gas inlet casing	51000	AA31 three holes								
Gas inlet casing	51000	A61								
Gas inlet casing	60		√	√	√	√	√	√	√	
Gas inlet casing	61000									
Disc	68000									
Compressor casing	72		√	√	√	√	√	√		
Air outlet casing	74/74000									
Air inlet casing	76/76000									
Silencer(KA02)	81000	KA20								
Air suction branch										
Description	P/N	TYPE	400	401	184-11	214-11	254-11	304-11	304-32	354-11
Space cover	46000/48000	BS+TS				√	√	√		√
Gas inlet casing	50	A1/A20radial 2 holes	√	√						
Gas inlet casing	50	A9/A21axial 2 holes								
Gas inlet casing	50	A11/A15radial 1 hole								
Gas inlet casing	50	AA31axial 3 holes								
Gas inlet casing	51000	AA12/AA21						√		
Gas inlet casing	51000	AA11							√	
Gas inlet casing	51000	AA11/21/31								√
Gas inlet casing	51000	AA11 one hole				√	√	√		√
Gas inlet casing	51000	AA21 two holes			√	√	√	√		√
Gas inlet casing	51000	AA31 three holes				√				√
Gas inlet casing	51000	A61								
Gas inlet casing	60									
Gas inlet casing	61000				√	√	√	√	√	√
Disc	68000					√	√	√	√	√
Compressor casing	72									
Air outlet casing	74/74000					√	√	√	√	√
Air inlet casing	76/76000					√	√	√	√	√
Silencer(KA02)	81000	KA20				√	√	√	√	√
Air suction branch										√
Description	P/N	TYPE	354-32	454-11	454-32	54D/E-3	564-11	564-32	714-32	714D-32
Space cover	46000/48000	BS+TS		√	√			√	√	
Gas inlet casing	50	A1/A20radial 2 holes								
Gas inlet casing	50	A9/A21axial 2 holes								
Gas inlet casing	50	A11/A15radial 1 hole								
Gas inlet casing	50	AA31axial 3 holes								
Gas inlet casing	51000	AA12/AA21								
Gas inlet casing	51000	AA11	√		√			√		
Gas inlet casing	51000	AA11/21/31		√						
Gas inlet casing	51000	AA11 one hole	√	√	√	√	√	√	√	√
Gas inlet casing	51000	AA21 two holes		√						

Gas inlet casing	51000	AA31 three holes		√						
Gas inlet casing	51000	A61						√		
Gas inlet casing	60									
Gas inlet casing	61000		√	√	√	√	√	√		√
Disc	68000		√	√	√	√	√	√	√	
Compressor casing	72									
Air outlet casing	74/74000		√	√	√	√	√	√		
Air inlet casing	76/76000		√	√	√	√	√	√		
Silencer(KA02)	81000	KA20	√	√	√		√	√		
Air suction branch			√	√	√					